



WH-LINK

AnchorLink Handheld Transmitter

Contains Transmitter Module FCC: Y82-SC14S / IC: 9578A-SC14S

The WH-LINK is a wireless handheld microphone with a sleek and lightweight design. It operates on the 1.9 GHz frequency. The WH-LINK is powered by two AA batteries and operates approximately 6 - 8 hours with fresh batteries.

Transmitter Specification:

Operating Voltage: 3V DC (2 AA Alkaline Batteries)

Frequency Range: 1880-1900 MHz

Modulation: DECT GFSK

Antenna: Embedded

Dimensions: 9.8" long, 2 1/4" diameter



1. On/Off Switch: Turns transmitter power on and off.
2. Volume UP: The Volume Up button adjusts the transmitter's audio level up.
3. Volume DOWN: The Volume Down button adjusts the transmitter's audio level down
4. Pair/Mute Button: Serves as a MUTE when push down once. Serves to PAIR mic to Anchorlink receiver. To PAIR hold once until Red LED turns OFF then release button, Hold PAIR button again until Green LED flashes.
5. Pairing LED: Solid GREEN LED indicates paired. Red LED will flash when battery is low
6. Battery Compartment: Insert two AA dry or rechargeable batteries into the compartment making sure the polarity of the batteries is correct.



Mic Capsule Specs:

- 7. Element Type: Dynamic
- 8. Polar pattern: cardioid
- 9. Frequency Response: 60-15KHz
- 10. Output Impedance: $400 (\pm 15\%) \Omega$ (at 1KHz)
- 11. Sensitivity: $-51 (\pm 3) \text{ dB}$ (at 1KHz) ($0\text{dB}=1\text{V/Pa}$) 1Pa (94 dB SPL at 1 kHz)
- 12. Directivity graph (at 1 kHz):

